





JBL PROCLEAN AQUA EX 10-35

Gravel cleaner for cleaning 10-35 cm aquariums

Suitable for:  



- Small, but smart and very effective gravel cleaner to siphon off waste from small aquariums
- Use: Hold the gravel cleaner under the water, briefly suck down the hose once and let the water flow into the bucket. Immerse the gravel cleaner into the substrate and the suction will remove the waste from the bottom
- The square cross section also enables you to siphon off waste from the corners of the aquarium
- Safe for the animals: removable protective sieve prevents accidental sucking in of plants, shrimps and fish
- Package contents: 1 gravel cleaner with Ø 35 mm, 12.5 cm height, incl. 1.5 m hose (9/12 mm)



JBL PROCLEAN AQUA EX 10-35



Accessories



JBL ClipSafe Vario

Adjustable multi-purpose
aquarium hose clips 9-27 mm



JBL PROCLEAN AQUA EX 10-35



Product information

Regular water change

Food, plant remains and metabolic products pollute the aquarium water. Since aquarium filters can't completely remove these substances from the water and a large part of the waste enters the aquarium bottom, a regular partial water change (about every 2 weeks 1/3 of the water content) needs to be carried out.

Always siphon off the waste from the substrate when carrying out a partial water change. After the partial water change a good water conditioner such as JBL Biotopol is vital to prepare the new tap water for fish.

Simple to use:


Hang the gravel cleaner in the aquarium, using your mouth briefly suck one end of the hose and hold the other end of the hose in the bucket. Water then flows into the bucket. Clean the bottom with the gravel cleaner. To finish, simply remove the gravel cleaner from the water.

Tip: To avoid swallowing water, you can also hold the whole hose underwater until it fills up, then pinch the end until it is over the bucket again. Then the water will continue to flow by itself.

How to clean the aquarium bottom properly:

Push the gravel cleaner into the aquarium substrate with twisting movements. The suction pulls the substrate and the dirt in the gravel cleaner upwards. The substrate falls back down under its own weight and only the dirt is sucked out of the aquarium. With fine sand, you can adjust the suction by lifting the gravel cleaner so that the light sand also falls back down. A sieve in the bell of the cleaner prevents fish and shrimp from being accidentally sucked in. The sieve can be removed for cleaning.

If you have a long-term substrate fertiliser under the covering gravel layer (e.g. JBL PROFLORA AQUA BASIS), do not insert the gravel cleaner far. Insert it only as deeply as the covering substrate layer is thick.

Further information	
FAQ	✓
Blog	✓
Press	✓
Laboratory/calculator	✗
Worth reading	✓
Spare parts	✗
Video	✓
GarantiePlus	✗
Instructions	✓
QR code	



JBL PROCLEAN AQUA EX 10-35



Product details

Article data	
Product name	JBL PROCLEAN AQUA EX 10-35
Art. No.	6142500
EAN number	4014162614254
EAN as barcode	
Ø	35 mm
Height	125 mm
Expiry months	-
RRP incl. VAT	16,84 €
Base price	-
Nominal filling quantity	-
Base quantity	1
Gross weight	201 g
Net weight	155 g
Weight change	-

Disposal	
Product name	JBL PROCLEAN AQUA EX 10-35
Art. No.	6142500
Green dot	✓
Group electronic waste	-
Disposal weight	-
Battery type	-
Battery return	-
Battery rechargeable	-
Disposal weight battery	-
Non-returnable glass	-
PPK	46 g
Plastic small	-
Plastic large	-
Disposal weight metal	0 g

Features	
Product name	JBL PROCLEAN AQUA EX 10-35
Art. No.	6142500
Animal species	Arowana, Axolotl, Barbels, Bettas, Bichirs/reedfish, Blowfish, Catfish, Cichlids (South America), Corals, Crayfish, Danions, Discus, Dwarf shrimps, Flowerhorn, Gobies, Goldfish, Gouramis, Guppy, Juvenile fish, Killifish, Livebearers, Loaches, Panchaxes, Rainbowfish, Snails, Spiny eels, Tetra, Veiltails, freshwater butterflyfish
Animal size	For all animal sizes



Features	
Animal age group	All aquarium fish
Volume of habitat	> 120 L
Material	plastic (ABS) / plastic (PS)
Food type	-
Colour	transparent / black
Dosage	-
Transport conditions	-



JBL PROCLEAN AQUA EX 10-35

Electronic label / illuminant	
Product name	JBL PROCLEAN AQUA EX 10-35
Art. No.	6142500
Ambient temperature	-
Start time	-
Mercury	-
Tube length	-
Service life	-
Lumen	-
CRI value	-
Dimmable	-
Switching cycles	-
PAR value	-
Energy efficiency class	-
UV-A	-
UV-B	-
UV-C	-
Colour temperature	-
Base designation	-

Technical data	
Product name	JBL PROCLEAN AQUA EX 10-35
Art. No.	6142500
Range in litres	-
Range from - to	-
Range in days	-
Range tank length	-
Output in watts	-
Output per hour	-
Output per day	-
Height	-
Length	-
Width	-
Diameter	-
Voltage	-
For	-
T8 26mm (watt)	-
T5 16mm (watt)	-
Size	-
Content for	-
Filter container volume	-
Volume filter media	-
Hose connections pressure/out	-
Hose connections suction/in	-
Delivery head	-



JBL PROCLEAN AQUA EX 10-35

Food type	-
Sub product type	-
Dosing	-





Additional information for the specialist trade sector

Article data	
Product name	JBL PROCLEAN AQUA EX 10-35
Art. No.	6142500
VAT	20%
Sales unit (SU)	3
Volume packaging	1.59l
Dimensions (l/w/h)	50 mm/120 mm/265 mm
Layer	144
Pallet	432
Category of products	2
Customs tariff	84132000
Country of origin	CN
Type of packaging	Faltschachtel/Karton

PU 1 data	
Product name	JBL PROCLEAN AQUA EX 10-35
Art. No.	6142500
PU 1 material	film gr
PU 1 weight	5 g
PU 1 length	120 mm
PU 1 width/depth	150 mm
PU 1 height	265 mm

PU 2 data	
Product name	JBL PROCLEAN AQUA EX 10-35
Art. No.	6142500
PU 2 material	cardboard gr
PU 2 weight	650 g
PU 2 length	550 mm
PU 2 width/depth	330 mm
PU 2 height	260 mm

Trade data	
Product name	JBL PROCLEAN AQUA EX 10-35
Art. No.	6142500
Till receipt text	AQAU EX 10-35
Shelf placement	-